

INTERMAC VERTMAX

Macchine verticali
Vertical machines



Catalogo Ricambi
Spare Parts Catalogue
Rel. 001



Il presente documento annulla e sostituisce tutte le precedenti versioni emesse.
La Intermac si riserva il diritto di apportare modifiche alla presente documentazione in qualsiasi momento e senza preavviso.
L'uso della stessa avviene da parte dell'utente sotto la propria responsabilità, sono escluse pertanto responsabilità della Intermac per danni diretti o indiretti dovuti all'uso di tale documentazione.
La riproduzione o distribuzione di questo documento o parte di esso non è autorizzata.

The present document delete and replace the precedent version released.
Intermac reserves the right at any time to alter this document without any notice whatsoever.
The customer will use it under his own responsibility. Intermac shall not be liable for any direct or indirect damages due to an improper use of it.
Unauthorized reproduction or distribution of this document, or any portion of it is not authorized.



Intermac

Via dell'Economia, 40
61122 Pesaro PU - Italy
Tel. +39 0721 483500
Fax +39 0721 481962
www.intermac.com
intermac.parts@intermac.com



CONI ISO40 - TOOL HOLDERS ISO 40
Speciali Per Vertmax - Special For Vertmax

Codice Codes	Descrizione Description	Diametro Diameter	Altezza Height
KR35200058	CONO DOPPIA MOLA VERTMAX D22 L50mm (con flangia speciale). Massimo pacco mole 40mm Tool Holder Cone D22 H50mm (special flange) for wheel pack max 40mm	22	50
KR35200059	CONO MOLA BASSA VERTMAX D22 L34mm (con flangia mola bassa) Tool Holder Cone D22 H34mm (flange for low wheel)	22	34
KR35200060	CONO MOLA ALTA VERTMAX D22 L34mm (con flangia mola alta) Tool Holder Cone D22 H34mm (flange for hight wheel)	22	34
F6408F0001	Fresa / Foretto - 1/2 gas Routers / Drills - 1/2 Inch gas		



KR35200059



F6408F0001



KR35200058

Intermac

Via dell'Economia, 40
 61122 Pesaro PU - Italy
 Tel. +39 0721 483500
 Fax +39 0721 481962
 www.intermac.com
 intermac.parts@intermac.com







Ricambi / Spares

<p>Gomma Ventose Suction Cups rubber</p> <table border="1"> <tr> <td>per vetri sottili for lower glass</td> <td>FNCN250003</td> </tr> <tr> <td>Gomma standard Normal Rubber</td> <td>FNX0150381</td> </tr> </table>	per vetri sottili for lower glass	FNCN250003	Gomma standard Normal Rubber	FNX0150381	
per vetri sottili for lower glass	FNCN250003				
Gomma standard Normal Rubber	FNX0150381				
<p>Piatto appoggio pezzo Suction Cups rubber plate</p> <table border="1"> <tr> <td>Code/Codice</td> <td>P1614P0046</td> </tr> </table>	Code/Codice	P1614P0046			
Code/Codice	P1614P0046				
<p>Supporto Ventosa Suction Cups Alluminium plate</p> <table border="1"> <tr> <td>Supporto/support</td> <td>FNAG102653</td> </tr> <tr> <td>Central o-ring</td> <td>3110A1986</td> </tr> </table>	Supporto/support	FNAG102653	Central o-ring	3110A1986	
Supporto/support	FNAG102653				
Central o-ring	3110A1986				
<p>Forchetta porta cono Tool holder support</p> <table border="1"> <tr> <td>New type</td> <td>FNZ0150157</td> </tr> </table>	New type	FNZ0150157			
New type	FNZ0150157				

<p>Rullo Rosso supporto vetri D60 Red roller D60</p> <table border="1"><tr><td>Code/Codice</td><td>FNY0200091</td></tr></table>	Code/Codice	FNY0200091	
Code/Codice	FNY0200091		
<p>Riferimento in teflon per tastatore Glass origin Teflon cylinder</p> <table border="1"><tr><td>Code/Codice</td><td>FNX0205793</td></tr></table>	Code/Codice	FNX0205793	
Code/Codice	FNX0205793		
<p>Ruota D60 traslo vetro Grey Roller Wheel</p> <table border="1"><tr><td>Code/Codice</td><td>F2722F0001</td></tr></table>	Code/Codice	F2722F0001	
Code/Codice	F2722F0001		
<p>Rotella pinza vetro * Nuovo tipo * Collet Wheel * New type *</p> <table border="1"><tr><td>Code/Codice</td><td>FNY0250063</td></tr></table>	Code/Codice	FNY0250063	
Code/Codice	FNY0250063		
<p>Rotella pinza vetro x Low-e Collet Wheel x Low-e</p> <table border="1"><tr><td>Code/Codice</td><td>FNY0250062</td></tr></table>	Code/Codice	FNY0250062	
Code/Codice	FNY0250062		

<p>Rotella pinza vetro * primo tipo * Collet Wheel * first type *</p> <table border="1" data-bbox="264 362 807 528"> <tr> <td>Code/Codice</td> <td>FNY0250043</td> </tr> <tr> <td></td> <td>NEW</td> </tr> <tr> <td></td> <td>FNY0250060+</td> </tr> <tr> <td></td> <td>FNY0250063</td> </tr> </table>	Code/Codice	FNY0250043		NEW		FNY0250060+		FNY0250063	
Code/Codice	FNY0250043								
	NEW								
	FNY0250060+								
	FNY0250063								
<p>Sensore mandrino Spindle Sensor</p> <table border="1" data-bbox="236 658 767 725"> <tr> <td>Normally Open</td> <td>H5664H0040</td> </tr> <tr> <td>Normally Closed</td> <td>H5664H0062</td> </tr> </table>	Normally Open	H5664H0040	Normally Closed	H5664H0062					
Normally Open	H5664H0040								
Normally Closed	H5664H0062								
<p>Sensore di Livello Water Level Sensor</p> <table border="1" data-bbox="236 1021 767 1055"> <tr> <td>Code/Codice</td> <td>2164A0822</td> </tr> </table>	Code/Codice	2164A0822							
Code/Codice	2164A0822								
<p>Sensore Magazzino Rotativo Rotative tool Change sensor</p> <table border="1" data-bbox="236 1346 767 1379"> <tr> <td>Code/Codice</td> <td>2164A1729</td> </tr> </table>	Code/Codice	2164A1729							
Code/Codice	2164A1729								
<p>Fotocellula Rulliere Photocell roller conveyor</p> <table border="1" data-bbox="236 1621 767 1655"> <tr> <td>Code/Codice</td> <td>F2164F0020</td> </tr> </table>	Code/Codice	F2164F0020							
Code/Codice	F2164F0020								

<p>Sensore zero asse CR1 Zero Sensor for CR1 axis</p> <table border="1" data-bbox="236 365 767 400"> <tr> <td>Code/Codice</td> <td>2164A0325</td> </tr> </table>	Code/Codice	2164A0325					
Code/Codice	2164A0325						
<p>Sensore magnetico Magnetic Sensor</p> <table border="1" data-bbox="236 640 767 676"> <tr> <td>Code/Codice</td> <td>2164A0365</td> </tr> </table>	Code/Codice	2164A0365					
Code/Codice	2164A0365						
<p>Sensore sicurezza carrelli Safety sensor for axis</p> <table border="1" data-bbox="236 940 767 1010"> <tr> <td>Old type</td> <td>2164A0771</td> </tr> <tr> <td>New type</td> <td>CCB2E00002</td> </tr> </table>	Old type	2164A0771	New type	CCB2E00002			
Old type	2164A0771						
New type	CCB2E00002						
<p>Flussostato Water Flow sensor</p> <table border="1" data-bbox="236 1236 767 1272"> <tr> <td>Code/Codice</td> <td>2164A0801</td> </tr> </table>	Code/Codice	2164A0801					
Code/Codice	2164A0801						
<p>Autoapprendimento Lastra Selflearning glass sheet <i>Fino al / before of 08-2014</i></p> <table border="1" data-bbox="236 1568 767 1671"> <tr> <td>Sensor</td> <td>2164A0862</td> </tr> <tr> <td>Optical fiber</td> <td>2164A1735</td> </tr> <tr> <td>Lens</td> <td>2164A1736</td> </tr> </table>	Sensor	2164A0862	Optical fiber	2164A1735	Lens	2164A1736	
Sensor	2164A0862						
Optical fiber	2164A1735						
Lens	2164A1736						

<p>Autoapprendimento Lastra Selflearning glass sheet <i>Dopo il / After 08-2014</i></p> <table border="1" data-bbox="236 371 769 407"> <tr> <td>Sensor</td> <td>CCB2L00004</td> </tr> </table>	Sensor	CCB2L00004			
Sensor	CCB2L00004				
<p>Tampone Teflon per misurazione spessore Teflonn finger for thickness detect</p> <table border="1" data-bbox="236 703 769 739"> <tr> <td>Codice/Code</td> <td>FNAA050244</td> </tr> </table>	Codice/Code	FNAA050244			
Codice/Code	FNAA050244				
<p>Sensore magnetico sportello acqua molatura Magnetic Sensor (Drill Pressor/Water Cover)</p> <table border="1" data-bbox="236 1034 769 1070"> <tr> <td>Code/Codice</td> <td>F2164F0041</td> </tr> </table>	Code/Codice	F2164F0041			
Code/Codice	F2164F0041				
<p>Sensore magnetico Sicurezza Safety sensor</p> <table border="1" data-bbox="236 1263 769 1330"> <tr> <td>Sensor</td> <td>CCB2H00006</td> </tr> <tr> <td>Connector</td> <td>2138A0467</td> </tr> </table>	Sensor	CCB2H00006	Connector	2138A0467	
Sensor	CCB2H00006				
Connector	2138A0467				
<p>Blocchetto ravvivatore foretti Drill Dressing block</p> <table border="1" data-bbox="236 1514 778 1550"> <tr> <td>90 x 60 x 60</td> <td>D10620</td> </tr> </table>	90 x 60 x 60	D10620			
90 x 60 x 60	D10620				

<p>Ravvivatore mola Lucidante Polishing Dressing tool</p> <table border="1" data-bbox="236 349 778 385"> <tr> <td>Finger shaft</td> <td>D9585</td> </tr> </table>	Finger shaft	D9585					
Finger shaft	D9585						
<p>Ravvivatore mola diamantata Diamond Dressing tool .</p> <table border="1" data-bbox="236 618 778 752"> <tr> <td>Pomice 50X15X100mm</td> <td>D10633</td> </tr> <tr> <td>Mola 150X6X32</td> <td>DCON199</td> </tr> <tr> <td>Mola 150X10X32</td> <td>DCON200</td> </tr> </table>	Pomice 50X15X100mm	D10633	Mola 150X6X32	DCON199	Mola 150X10X32	DCON200	
Pomice 50X15X100mm	D10633						
Mola 150X6X32	DCON199						
Mola 150X10X32	DCON200						
<p>Presetter – ricambi / Spares</p> <table border="1" data-bbox="236 945 778 1048"> <tr> <td>Disco / disc</td> <td>FNX0150406</td> </tr> <tr> <td>Spina di rottura Braking pin</td> <td>2164A0832</td> </tr> </table>	Disco / disc	FNX0150406	Spina di rottura Braking pin	2164A0832			
Disco / disc	FNX0150406						
Spina di rottura Braking pin	2164A0832						
<p>Filtro acqua 10micro Water Filter 10micro</p> <table border="1" data-bbox="236 1214 778 1249"> <tr> <td>Codice/Code</td> <td>2422A0135</td> </tr> </table>	Codice/Code	2422A0135					
Codice/Code	2422A0135						
<p>Filtri disoleatore/condensa Oil/water Filters</p> <table border="1" data-bbox="236 1514 778 1711"> <tr> <td>Verde/Green D40 L120mm</td> <td>2422A0204</td> </tr> <tr> <td>Bianco/White 50µ D16 L27mm</td> <td>2422A0209</td> </tr> <tr> <td>Bianco/White 50µ D30 L35mm</td> <td>2422A0224</td> </tr> </table>	Verde/Green D40 L120mm	2422A0204	Bianco/White 50µ D16 L27mm	2422A0209	Bianco/White 50µ D30 L35mm	2422A0224	
Verde/Green D40 L120mm	2422A0204						
Bianco/White 50µ D16 L27mm	2422A0209						
Bianco/White 50µ D30 L35mm	2422A0224						

SOFTWARE + OPTIONAL**Bsolid Vertmax**

Bsolid	KR35200092
2° Licenza	KR35200093
2° Dongle	KR35200093

**Intermac**

Via dell'Economia, 40
61122 Pesaro PU - Italy
Tel. +39 0721 483500
Fax +39 0721 481962
www.intermac.com
intermac.parts@intermac.com



Intermac

Via dell'Economia, 40
61122 Pesaro PU - Italy
Tel. +39 0721 483500
Fax +39 0721 481962
www.intermac.com
intermac.parts@intermac.com



Vi preghiamo di contattarci per qualsiasi informazione o ordine al seguente indirizzo:

Intermac.parts@intermac.com

indicando nell' **oggetto** il vs numero d'ordine e poi una delle seguenti parole chiave indipendentemente dal tipo macchina:

INFO per richieste generali (un codice , un kit, ecc...)
OFFER per richieste di prezzo e disponibilità
DOWN per ordini relativi a MACCHINA FERMA
URGENT per ricambi urgenti
STOCK per ricambi normali non urgenti e per lo stock

Contact us to the following mail address for every information or order:

Intermac.parts@intermac.com

indicating in the **subject** your order number and afterwards one of the following keywords regardless of machine type :

INFO for general info inquiries (a part number, a kit etc...)
OFFER for a price inquiry
DOWN for a m/c down order
URGENT for an urgent spare parts order
STOCK for a normal or stock spare parts order

Intermac

Via dell'Economia, 40
61122 Pesaro PU - Italy
Tel. +39 0721 483500
Fax +39 0721 481962
www.intermac.com
intermac.parts@intermac.com



